


The SpiderCapo



Positioning the SpiderCapo on your Guitar Fingerboard

1. Place the capo over the fingerboard with the KNOB positioned on the bass side [low "E" string]. The FINGERS should be in the "up" position as shown.
2. Unscrew the KNOB [counterclockwise] and open the END PIECES to a width slightly greater than the guitar fingerboard.



- *3. Place the treble side TABS just behind the fret that you want to capo.
4. Lower the bass side so that the TABS rest on the fingerboard and the LEATHER PADS align to the sides of the neck.

5. Turn the KNOB clockwise until the end pieces are in contact with the sides of the neck. Now, tighten securely with at least one full turn of the KNOB. You may tighten beyond one turn if needed, the organic leather pads will protect the neck. ▶



6. Use the FINGER HANDLES to align the fingers over the strings.

7. Rotate the FINGER HANDLES to capo each individual string as desired. We call this tuning (shown in the photo) "020022" because the SpiderCapo is on the 2nd fret and the 5th [A], 2nd [B], and 1st [E] strings are capoed. ▶

Note: You will feel a stopped 'down' position but, you need not rotate the finger that much. You can fine tune the string by moving the finger back and forth when the string is depressed.

* You can also position the forward Tab in front of the fret. Feel free to experiment.

